

Stylus Cleaner ST-50 取扱説明書

特徴

ST-50 では産業用クリーンルームでホコリ取り用に開発された特殊ウレタンゲル素材を使用しております。この素材は微細なホコリやチリの侵入が許されないクリーンルームの厳しい要求を満たす為に開発された特殊なウレタンゲルであり針先に付着した微細なホコリも残らず吸着致します。(光カートリッジのみならず MM/MC カートリッジでもご使用頂けます。)



Before



After

ご使用方法

ターンテーブルの上にセットした ST-50 の特殊ウレタンゲルの上に針先を 2～3 回落として頂くだけでクリーニングが完了します。

(針先を痛める可能性がありますので絶対にクリーニング中にターンテーブルを回転させないで下さい。)



お手入れ方法

ST-50 で使用されている特殊ウレタンゲルは粘着度が落ちた場合でも水洗いすることで自己粘着性が回復し何度でもご使用頂けます。

水洗いする際は洗剤等は使わず水道水で付着したホコリを洗い流した後 30 分程自然乾燥させて頂くだけで新品同様の粘着度が復活します。



**Features**

ST-50's cleaning gel is made by Urethane Resin developed specially for the micro-dust cleaning purpose in the clean-room.

Strict and high cleaning performance is required for such applications.

ST-50 gives you the upmost satisfaction of the stylus cleaning.

ST-50 cleans your stylus at your pre-set needle pressure of the tone arm.



Before



After

How to Use

Simply drop the needle tip on the ST-50 special Urethane gel set on the turntable 2-3 times, and the cleaning is completed.

(Do not rotate the turntable while cleaning as it may damage the needle tip.)

**Washable Urethane Cleaning Gel**

ST-50 gives you the best stylus cleaning performance all the time.

Urethane Gel is washable and re-usable. Just wash it under tap water gently.

Let it dry for 30 minutes at room temperature.

It recovers its cleaning performance as new as ever.

